

FAQ

1. What type of ACs does it work with?

The infrared AC controller works with any remote-controlled split, cassette, or window AC.

2. What type of battery is used?

The infrared AC controller works on three standard AAA batteries

3. How is it mounted?

There are two ways to mount the infrared AC controller on a wall. The first, is by using screws, and the second, is by using double sided tape.

4. How does the infrared AC controller control the AC?

The infrared AC controller controls the AC by using infra-red signals just like the AC remote. There is no interference with the power supply of the AC.